



## Pro-Rite® Markerboard Care & Maintenance

---

### **DAILY CARE & MAINTENANCE**

- For the initial cleaning, wipe your board with a clean cloth moistened with markerboard cleaner or Marsh's recommended Mar-Kleen® cleaner.
- Rinse with clear water. This step is simple but very important.
- Wipe dry with a clean cloth.
- If your board is used daily, the cleaning should be performed at least 2 to 3 times a week.
- More thorough cleaning may be required if writing is left on the board for more than 2 days.
- **DO NOT** use any organic cleaners (orange, lime) as it causes erasibility issues.

---

### **REMOVING PERMANENT MARKER – 2 methods**

- 1) Trace over permanent marker with a Marsh dry-erase maker. Erase. Repeat if necessary.
- 2) Moisten a clean, dry cloth with isopropyl alcohol.
  - Wipe the board in a circular motion to loosen marker residue.
  - Rinse with clear water.
  - Dry the board with a clean cloth.
  - Repeat these steps as often as necessary to remove all residues.

---

### **REMOVING CRAYON AND TAPE -- *The same procedure is used to remove both crayon and tape.***

- Dampen a clean, dry cloth with water.
- Sprinkle a small amount of non-abrasive cleanser, such as SoftScrub® without bleach, onto the cloth. For best results, follow non-abrasive cleaner manufacturer's instructions found on the product label.
- Begin cleaning a small, manageable area using a back and forth horizontal motion. Use normal pressure as if you were cleaning a window.
- Wipe off all residues with a dry cloth.
- Rinse well with clear water.
- Wipe dry with a clean cloth.
- Follow the same procedure for the remainder of the board.

If you have any questions, call your local Marsh distributor or contact Marsh directly at [vpsales@marsh-ind.com](mailto:vpsales@marsh-ind.com).